

# LIBRAVIEW



IT WORKS IN CONJUNCTION WITH **LIBRACELLS**, **LIBRABASIC** AND **LIBRAPRO** CONTROLLERS. THE SOFTWARE ENABLES USERS TO GET A LIVE READOUT OF WEIGHTS PLACED ON **LIBRACELLS**, AS WELL AS OFFERING LOGGING AND ARCHIVING FACILITIES. THESE ARE AVAILABLE IN KG OR LBS.

THE **LIBRAVIEW** SOFTWARE ALLOWS ALL ACTIVITY TO BE LOGGED AND EXPORTED TO A **COMMA SEPARATED VALUE (.CSV)** FILE WHICH CAN BE OPENED BY ANY TEXT OR SPREADSHEET APPLICATION. IT IS ALSO POSSIBLE TO AUTOMATE THIS PROCESS TO ARCHIVE LOGS.

WHEN USED IN CONJUNCTION WITH A **LIBRAPRO** CONTROLLER, RELAYS CAN BE TRIGGERED WHEN AN UNDERLOAD OR OVERLOAD IS DETECTED BY THE **LIBRACELLS**. THESE RELAYS CAN BE PROGRAMMED TO TRIGGER SOUNDERS OR VISUAL WARNINGS AS WELL AS TRIGGERING AN EMERGENCY STOP.



## SOFTWARE FEATURES

WORKS WITH **USB** AND/OR **ETHERNET** INTERFACES  
VIEW INDIVIDUAL LOADS OR GROUP LOADS  
SET **OVERLOAD** AND **UNDERLOAD** WARNINGS AND ALARMS  
VIEW DATA AS FIGURES OR GRAPHS  
FULL DATA LOGGING CAPABILITIES

## MINIMUM SYSTEM REQUIREMENTS

**WINDOWS XP, VISTA OR 7**  
**1 x USB** OR **1 x ETHERNET PORTS**  
**1024 x 768** MINIMUM RESOLUTION